

Accessory

Manual Clamping Head Changing Tool



<i>Model</i>	<i>Clamping Head</i>
CCT42	42S/SR/RL
CCT52	52S/SR/RL
CCT65	65S/SR/RL
CCT80	80S/SR/RL

Larger models of the clamping head require pneumatic tools.
Please consult the pre-sales service staff.

Turning Fixture



<i>Model</i>	<i>Clamping Head</i>
TF42	42EM
TF52	52EM
TF65	65EM
TF80	80EM

Used in conjunction with the EM clamping head,
it can adjust the clamping diameter of the collet.